



## WEST VIRGINIA

COMMISSION FOR THE DEAF AND HARD OF HEARING

# ACCESSIBLE SMOKE ALARM PROJECT

## Installation Guide



### First Alert Alarm

Place this alarm in a **hallway near the bedroom(s) where the LifeTone Bed Alarm will be used.**

It may be installed **on the ceiling or the wall.**

**-Place alarm 4 to 12 inches away from the corner of the ceiling and the wall.**

**-Do not place alarm near the bathroom. Steam from the shower could cause false alarms.**



### Gentex

Place this alarm in the **room where most time is spent. Typically this will be your living room or den.**

Place the alarm **4 to 12 inches away from the corner of the ceiling and the wall.**

This alarm requires an **outlet. Make sure the cord is within reach.**

**-Do not choose an outlet that is controlled by an "on-off switch."**



### LifeTone Alarm

Place this alarm in the **bedroom of a Deaf or Hard of Hearing person.**

See page 2 for an depth setup guide.



## WEST VIRGINIA

### COMMISSION FOR THE DEAF AND HARD OF HEARING

# ACCESSIBLE SMOKE ALARM PROJECT

## LifeTone Alarm Setup Guide



**\*\*Please read alarm instructions first. This guide is a supplementary step-by-step to assist in installation\*\***



1. Put batteries in as directed **and** plug the alarm into an outlet.
2. Plug the bed shaker into the back of the alarm
3. You will see the word TEST flashing
4. Press the **red** SILENCE/TEST button on the back of the alarm. TEST will **stop** flashing
5. Wait for TEST to begin flashing again. This should take 30 seconds.

6. Go to your First Alert alarm located in your hallway.  
-Press and hold TEST button



7. Within 30 seconds of the test alert of your First Alert alarm, your LifeTone alarm should begin flashing the word FIRE with an orange light.
8. To stop the alarm, press the **red** SILENCE/TEST button on the back.
9. You will see "12 hr" flashing on the screen. Press the SET CLOCK button.
10. Use the + and — buttons to set the hour of time. Press SET CLOCK again.
11. Use the + and — buttons to set the minute of time. Press SET CLOCK again.
12. Use the + and — buttons to set the year. Press SET CLOCK again.
13. Use the + and — buttons to set the month. Press SET CLOCK again.
14. Use the + and — buttons to set the day. Press SET CLOCK again.
15. You will see an E flashing. This means English. Press SET CLOCK.
16. You can set an alarm by holding the "SET ALARM" button until the hour is flashing.
17. Use the + and — buttons to set the hour for the alarm. Press SET ALARM again.
18. Use the + and — buttons to set the minute for the alarm. Press SET ALARM again.
19. Press ON/OFF to turn the alarm on and off. When the bell in the **left corner** is shown, your alarm is **on**. Pressing ON/OFF again will make the bell disappear, and your alarm will be **off**.

#### TIPS:

-SNOOZE = your alarms will shut off for ten minutes

#### ERROR MESSAGES:

-BATT = low battery. Change the batteries as soon as possible

-BEDS = bed shaker error. Check to make sure it is plugged in correctly. If BEDS alert continues, contact the Commission for troubleshooting